



- This notice serves as a quick guide to important points to remember
- The machine should be used by authorised trained operators only
- All operators must read & understand the operator manual prior to use



SCAN ME

HOW DOES IT WORK?

The EC52 is stationary on the first step of the escalator and roller brushes clean each step in turn as the escalator moves. Once all steps have been cleaned on that side, the brush head of the EC52 is swivelled around to repeat the process on the other side of the steps. Cleaning is carried out in two parts, the dry phase (to remove dust, dirt and debris) and the wet phase (to clean and dry)



BEFORE USE

- Check brushes
- Check recovery tank is empty and solution tank is full
- Check filter

OPERATION

Step 1 - DRY PHASE

- Fit GREY brushes
- Fit the external vacuum cleaner hose to the escalator machine **BLUE** hose
- **Ensure the water is switched OFF**



FIT GREY BRUSHES



REMOVE SIDE PANEL



ATTACH BLUE HOSE

Begin by cleaning the right side of the escalator first. Switch the brushes ON and carefully manoeuvre the machine onto the escalator with the steps moving towards you and **apply the BRAKE** (be extra careful if you are cleaning at the top of the escalator as the machine is moving away from you). The dry phase should take approximately 10 minutes (you should notice a significant difference very quickly). Now you must swivel the brushes in order to clean the other side of the escalator. There is a **BLACK** knob located on the right hand side of the brush container, swivel the full head of the machine and secure the **BLACK** knob into place (ensure it is properly secure otherwise you could cause damage to the escalator). When you have completed the dry phase on both sides you are ready to move onto the **WET PHASE**

CALL 0141 647 4200 FOR ASSISTANCE

Step 2 – WET PHASE

- Fit **BLACK** brushes
- Fit the external vacuum cleaner hose to the escalator machine **RED** hose



FIT BLACK BRUSHES



REMOVE SIDE PANEL



ATTACH RED HOSE

Switch the brushes on and as with the dry phase, very carefully manoeuvre the machine onto the escalator with the steps moving towards you and **apply the BRAKE** (be extra careful if you are cleaning at the top of the escalator as the machine is moving away from you).

- Switch water on
- Switch vacuum on
- Leave machine to clean escalator
- After 5-10 minutes switch water off
- Leave machine to vacuum any residue left on the escalator

Once all steps have been cleaned on the first side, swivel head (ensuring to secure black knob firmly into place otherwise you could cause damage to the escalator) and repeat process to clean the other side of the steps.

AFTER USE

- Switch off vacuum, brushes and power
- Empty tanks
- Check brushes
- Clean filter
- Wipe machine down with damp cloth

DO NOT use with non-approved detergent (only a very small amount of low-foam s/dryer detergent)